

## CAR-MON WELDING TREE

1. Unpack and check all materials. Look for any concealed damage, if damage is present, notify carrier immediately. Car-Mon cannot be responsible for any damage not reported to the carrier.
2. Install vertical pole with bolts or by welding to steel support. Make sure pole is level and plumb.
3. Install components in order shown below.
4. Attach tubing assembly to articulated arm by attaching bolt through band on tubing receptor.
5. Attach C clamp to holding bar.
6. Attach tubing to duct or exhaust outlet.

